

Injectors (Sequential)

No. of engine Cylinders	Injector Name	ECU Pin	Cylinder Number
4	Injector 1	M2H2	1
	Injector 2	M2G3	2
	Injector 3	M2G2	3
	Injector 4	M2H3	4

Injectors (batched - Semi Sequential)

No. of engine Cylinders	Injector Name	ECU Pin	Cylinder Number
4	Injector 1	M2H2	1
	Injector 2	M2G3	2
	Injector 3	M2G2	3
	Injector 4	M2H3	4

On Plug Coils

No. of engine Cylinders	Coil Name	ECU Pin	Cylinder Number
4	Coil 5	M1G3	1
	Coil 1	M1G2	2
	Coil 6	M1H3	3
	Coil 4	M1H2	4

Double Coils

No. of engine Cylinders	Coil Name	ECU Pin	Cylinder Number
4	Coil 5	M1G3	1,4
	Coil 6	M1H3	2,3

Order: 1-5-3-6-2-4

No. of engine Cylinders	Injector Name	ECU Pin	Cylinder Number
6	Injector 1	M2H2	1
	Injector 5	M2G1	2
	Injector 4	M2H3	3
	Injector 6	M2H4	4
	Injector 3	M2G2	5
	Injector 2	M2G3	6

Order: 1-5-3-6-2-4

No. of engine Cylinders	Injector Name	ECU Pin	Cylinder Number
6	Injector 1	M2H2	1
	Injector 2	M2G3	2
	Injector 5	M2G1	3
	Injector 6	M2H4	4
	Injector 3	M2G2	5
	Injector 4	M2H3	6

Order: 1-5-3-6-2-4

No. of engine Cylinders	Coil Name	ECU Pin	Cylinder Number
6	Coil 5	M1G3	1
	Coil 3	M1G4	2
	Coil 4	M1H2	3
	Coil 2	CPM3	4
	Coil 6	M1H3	5
	Coil 1	M1G2	6

Order: 1-5-3-6-2-4

No. of engine Cylinders	Coil Name	ECU Pin	Cylinder Number
6	Coil 5	M1G3	1,6
	Coil 6	M1H3	2,5
	Coil 4	M1H2	3,4

Order: 1-8-4-3-6-5-7-2

No. of engine Cylinders	Injector Name	ECU Pin	Cylinder Number
8	Injector 1	M2H2	1
	Injector 8	M2E4,M2F4	2
	Injector 2	M2G3	3
	Injector 4	M2H3	4
	Injector 6	M2H4	5
	Injector 5	M2G1	6
	Injector 7	M2G4	7
	Injector 3	M2G2	8

Order: 1-8-4-3-6-5-7-2

No. of engine Cylinders	Injector Name	ECU Pin	Cylinder Number
8	Injector 1	M2H2	1
	Injector 7	M2G4	2
	Injector 8	M2E4,M2F4	3
	Injector 5	M2G1	4
	Injector 2	M2G3	5
	Injector 4	M2H3	6
	Injector 6	M2H4	7
	Injector 3	M2G2	8

Order: 1-8-4-3-6-5-7-2

No. of engine Cylinders	Coil Name	ECU Pin	Cylinder Number
8	Coil 5	M1G3	1
	Coil 8	CPM1	2
	Coil 1	M1G2	3
	Coil 4	M1H2	4
	Coil 2	CPM3	5
	Coil 3	M1G4	6
	Coil 7	CPM2	7
	Coil 6	M1H3	8

Order: 1-8-4-3-6-5-7-2

No. of engine Cylinders	Coil Name	ECU Pin	Cylinder Number
8	Coil 5	M1G3	1,6
	Coil 1	M1G2	2,3
	Coil 4	M1H2	4,7
	Coil 6	M1H3	5,8